

Year 2008 Speedplay Road Shoe Compatibility Guide***

SHOES COMPATIBLE WITH FACTORY-INSTALLED 1-F AND 1-R SNAP-SHIMS

Answer
*Carnac
Duegi
*Exustar

Gaerne
Look
Luck
Nike

*Northwave
*Pearl Izumi
Performance
*Rocket 7

*Shimano
*Sidi
SixSixOne
*Specialized

*Time
Vittoria

*See excepted models below

COMPATIBLE SHOES REQUIRING ALTERNATIVE CLEAT INSTALLATION

adidas 4-hole: Omit base plate. See **4-HOLE CARBON-FIBER SOLES**.

adidas '06 & Earlier: Use 1-F and 1-R Snap-Shims.

Carnac insert-type: Omit base plate. Use Carnac-supplied UCS3 insert. Requires Speedplay 4x15-8 Cleat Fastening Screws (Part #13015).

Diadora '08: **Remove 1-F and 1-R Snap Shims and install 4-F and 4-R Snap Shims.

Diadora Alu: Call Speedplay for installation instructions.

Diadora Multiped: Omit base plate. Use Diadora-supplied Time/Speedplay insert.

DMT insert-type: **Remove Snap-Shims from base plate. Sole cavity must be modified to allow full rearward cleat adjustment. See detailed photo at www.speedplay.com.

DMT SLHC '07 - '08: **Remove 1-F and 1-R Snap Shims and install 4-F and 4-R Snap Shims.

DMT FG Concept '08: **Remove 1-F and 1-R Snap Shims and install 4-F and 4-R Snap Shims. May require "Extra Shim" under rear-outboard cleat-mounting screw of each base plate.

Exustar: Use 1-F and 1-R Snap-Shims. May require "Extra Shim" under rear-inboard cleat-mounting screw of each base plate.

Lake 3-hole '08: **Remove 1-F and 1-R Snap Shims and install 4-F and 4-R Snap Shims.

Lake 4-hole '08: Omit base plate. See **4-HOLE CARBON-FIBER SOLES**.

Louis Garneau Carbon Ergo: Use 1-F and 1-R Snap Shims. May require "Extra Shim" under rear-inboard cleat-mounting screw of each base plate.

Louis Garneau '07 - '08: **Remove 1-F and 1-R Snap Shims and install 4-F and 4-R Snap Shims.

MEM '06 & earlier: Requires #3 shim kit (Part #13395 sold separately.) **Remove 1-F and 1-R Snap-Shims and install 3-F and 3-R Snap-Shims.

Nalini '08: **Remove 1-F and 1-R Snap Shims and install 4-F and 4-R Snap Shims.

Nalini '06 - '07: Call Speedplay for installation instructions.

Northwave Aerator & Genetix '06 & earlier: Requires #3 shim kit (Part #13395 sold separately.) **Remove 1-F and 1-R Snap-Shims and install 3-F and 3-R Snap-Shims.

Northwave Evolution 4-hole: Omit base plate. Requires Speedplay 4x15-8 screws (Part #13015). See **4-HOLE CARBON-FIBER SOLES**.

Northwave Centurion, Mirage, Solo, Diana Road, Husky: Omit base plate. Use Northwave-supplied Time/Speedplay insert. Requires 4x13-8 Cleat Fastening Screws (Part #13295) available from Speedplay.

Pearl Izumi I Beam Sole: Use 1-F and 1-R snap shims. May require "Extra Shim" under rear-inboard cleat-mounting screw of each base plate.

Rocket 7 4-hole: Omit base plate. See **4-HOLE CARBON-FIBER SOLES**.

Shimano carbon-fiber '04 & earlier: Use 1-F and 1-R Snap-Shims. Compatible only with Zero Pedal Systems.

Shimano '07: **Remove 1-F and 1-R Snap Shims and install 4-F and 4-R Snap Shims.

Sidi noncarbon-fiber '04 & earlier: Requires #3 shim kit (Part #13395 sold separately.) **Remove 1-F and 1-R Snap-Shims and install 3-F and 3-R Snap-Shims. Do not use the removable Sidi-supplied insert.

Specialized '07: **Remove 1-F and 1-R Snap Shims and install 4-F and 4-R Snap Shims.

Specialized '01 - '06: Use 1-F and 1-R Snap-Shims. May require "Extra Shim" under rear-inboard cleat-mounting screw of each base plate.

Time carbon-fiber '08: Use 1-F and 1-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.

Time '06 models: Use 1-F and 1-R Snap Shims. May require "Extra Shim" under rear-inboard cleat-mounting screw of each base plate.

Time TBT Integral 4-hole sole: Omit base plate. Use Time-supplied Time/Speedplay insert. Requires Speedplay 4x15-8 screws (Part #13015).

Time TBT 4-hole Universole: Omit base plate. Requires Speedplay 4x15-8 Cleat Fastening Screws (Part #13015).

****Ensure the factory-installed cleat nuts remain in the base plate.**

INCOMPATIBLE SHOES

adidas '07 - '08

DMT '08 Mag Force & Mag Light

Exus

Lake 115 & 125

Nalini '05 & Earlier

Northwave Carbonio

Shimano without 3-hole (Look) configuration

Shimano carbon fiber '04 & earlier (**X Series not compatible**)

Time Elan

All MTB shoes and road shoes with MTB-type lugged soles.

4-HOLE CARBON-FIBER SOLES: Must use Stainless Steel Wear Protector Shim Kit (Part #13290), sold separately and available from Speedplay, to prevent contact between the pedal body and the carbon-fiber sole. Carbon fiber is a poor wear surface and unless a wear protector is used, damage to both the pedals and shoes will result.

WARNING! - Do not use the Snap-Shim Cleat mounting screws with any previous models of Speedplay X Cleats including the Slim Line Cleat. The Snap-Shim Cleat mounting screw heads are too small and may pull through the older base plates. This may cause the cleat to pull off the shoe causing a fall that may result in severe injury.

*****See detailed photos of select sole mountings and the latest updates for shoe compatibility at www.speedplay.com or call the Speedplay Tech Dept. at 1-800-468-6694 (PST).**